



## Clear Prep System Cleanser Procedures

To be used for maintaining your polish system  
or when installing a new polish (Part #33CP-C)

Before installing new polish into your slurry system or when recharging your system, it is important to thoroughly clean and flush the system and all supply and return lines with Clear Prep System Cleanser (Part #33CP-C) to remove any debris from the lines.



### Mixing Instructions

1. Combine 5-gallons of tap or DI water with one bottle of Clear Prep System Cleanser Concentrate
2. Mix thoroughly

### System Cleaning Procedure

1. Fully drain the system of any old polish. Rinse existing filter or replace with a new, 300 micron filter bag.
2. Fill the reservoir with hot tap water and allow it to circulate through the system, including the attached polishers, for 15 - 20 minutes. Repeat several times until water runs clear.
3. Drain the water, replace with fresh hot water and allow it to circulate again for another 15-20 minutes.
4. Drain and replace the water with diluted Clear Prep System Cleanser. Allow it to circulate for 1-2 hours. (If you customarily leave the system loaded with polish overnight, leave the Clear Prep in the system overnight. In the morning briefly run the Clear Prep through the system for 5 minutes to remove any loosened debris.)
5. Drain the system and clean or replace any filters.
6. Rinse system with warm water and remove all rinse water from feed and drain lines by either blowing the lines out with compressed air or by using a wet/dry vacuum.
7. Fill tank with polish.
8. To prevent any dilution or contamination of the new polish, after filling the tank with polish, plug the polishing machine bowl drains (use a rag or paper towels) and turn the pump on for a few seconds to pump out any remaining water from the feed lines into the bowl. Turn off the pump and vacuum out the bowls. Remove the drain plugs then initiate polish flow.

**TIP:** Fill a spray bottle with diluted Clear Prep to have on hand to spot clean spouts, bowls the slurry tank and chilling coil.

**Read SDS sheet before use.**





**LOOK TO PSI**  
Optical Laboratory  
Supplies & Equipment

## Clear Prep Concentrate

### Polish System Cleanser

An easy and economical way to remove contaminants from your polish lines. Recommended before the installation of new polish and bi-yearly to keep lines free flowing.

### Features & Benefits

- Used to maintain and clean polish lines or when installing new polish
- Keeps line free flowing, removing polish and swarf build-up
- Use twice a year to remove debris in lines that can cause scratching
- Economical and easy to use



*Discharge from lines after flushing with Clear Prep*

### Ordering Information:

Part #: 33CP-C, 760ml concentrate (makes 5 gallons)

Quantity: It is recommended you use approximately the same volume of Clear Prep as the tank's capacity.

Example:

PSI's 911 Slurry System (5 gallon tank) use one 760ml of Clear Prep Concentrate diluted

PSI's 913 Slurry System (11 gallon tank) use two 760ml of Clear Prep Concentrate diluted

**To Order Call 800-237-8154, Fax 800-330-3800  
or e-mail [info@LookToPSI.com](mailto:info@LookToPSI.com)**



**PRACTICAL SYSTEMS INC.**

11617 Prospect Road • Odessa, FL 33556  
(727) 376-7900 • Fax (727) 372-1900  
(800) 237-8154 • Fax (800) 330-3800  
[www.LookToPSI.com](http://www.LookToPSI.com)