

390A TAPE DISPENSER

With 110 Volt Hot Knife

Operating Instructions



PRACTICAL SYSTEMS, INC.

11617 Prospect Road • Odessa, FL 33556
(800) 237-8154 • Fax (800) 330-3800

OPERATING INSTRUCTIONS

Mounting Instructions

IMPORTANT: Before you use the Tape Dispenser, you **MUST** mount it to a work bench with the two screws supplied. Choose a convenient location.

Loading

1. Open the cover on the tape dispenser.
2. Remove the tape roll holder.
3. Load the tape on the holder so that the tape will peel off the top of the roll.
4. Peel about one foot of tape off of the roll and separate from the backing. Fold the backing paper on a 45° angle to form a point. Slide the backing through the slot in the lens ram base and out the slot in the front of the dispenser.
5. Feed the tape through the slot in the cover of the dispenser.
6. Close the cover and tighten screw.

Operating

1. Plug in the hot knife.
2. Place the lens on the lens platform and center it.
3. Pull enough tape through the slot to reach the front of the dispenser. It may be necessary to pull the backing and the tape simultaneously.
4. Depress the handle on the left side to lock closure ring over the tape and lens. Make sure that the handle locks in position.
5. Depress the handle on the right side until the tape is stretched **TIGHTLY** over the lens. Lock in position with the ratchet.
6. Cut the tape around the perimeter of the lens with the hot knife.
7. Remove lens
8. Release both handles.

For best results and longer life, unplug hot knife when not in use.

WARNING: The hot knife should be plugged into a 110V outlet equipped with GFCI (Ground Fault Circuit Interrupt) to prevent possible electric shock.

CAUTION: Always use handle on hot knife because metal parts can get very hot.

390E TAPE DISPENSER

With 220 Volt Hot Knife

Operating Instructions



PRACTICAL SYSTEMS, INC.

11617 Prospect Road • Odessa, FL 33556
(800) 237-8154 • Fax (800) 330-3800

OPERATING INSTRUCTIONS

Mounting Instructions

IMPORTANT: Before you use the Tape Dispenser, you **MUST** mount it to a work bench with the two screws supplied. Choose a convenient location.

Loading

1. Open the cover on the tape dispenser.
2. Remove the tape roll holder.
3. Load the tape on the holder so that the tape will peel off the top of the roll.
4. Peel about one foot of tape off of the roll and separate from the backing. Fold the backing paper on a 45° angle to form a point. Slide the backing through the slot in the lens ram base and out the slot in the front of the dispenser.
5. Feed the tape through the slot in the cover of the dispenser.
6. Close the cover and tighten screw.

Operating

1. Plug in the hot knife.
2. Place the lens on the lens platform and center it.
3. Pull enough tape through the slot to reach the front of the dispenser. It may be necessary to pull the backing and the tape simultaneously.
4. Depress the handle on the left side to lock closure ring over the tape and lens. Make sure that the handle locks in position.
5. Depress the handle on the right side until the tape is stretched **TIGHTLY** over the lens. Lock in position with the ratchet.
6. Cut the tape around the perimeter of the lens with the hot knife.
7. Remove lens
8. Release both handles.

For best results and longer life, unplug hot knife when not in use.

WARNING: The hot knife should be plugged into a 220V outlet equipped with GFCI (Ground Fault Circuit Interrupt) to prevent possible electric shock.

CAUTION: Always use handle on hot knife because metal parts can get very hot.

